




powered by  **BM PRO**

HELP GUIDE

CONFIGURING JAYCOMMAND DISPLAY VIA BYO DEVICE




INSTALLATION INSTRUCTIONS

1. Ensure BYO App is the most recent version.
2. The App must be at Onboarding Screen.
3. On the JAYCOMMAND Display, navigate to pairing screen and pair with BYO device.



4. Configure RV



TIP 1: Make sure some change has been made to Model and options, else the system will not exit the configuration screen. You will have to restart the app or press back until the main page is seen.

TIP 2: After Pressing Confirm WAIT for the App to exit the Configuration page to exit to home page AND App to reset; This will grey out the app and then get back to the HOME screen.

5. After configuring, check that the serial number set is correct on the App by going to the About JAYCOMMAND in the settings page
6. Unpair the APP from the Node
 - Go to General settings
 - Click on Bluetooth Settings
 - Click Unpair RV
7. This will take you back to step 2